

Article XI – Definitions

DESIGN FLOOD ELEVATION (DFE) - The Base Flood Elevation (BFE) plus an additional two (2) feet of Freeboard. In areas designated as Zone AO, the Design Flood Elevation shall be the elevation of the highest existing grade of the building's perimeter plus the depth number (in feet) specified on the flood hazard map.

Effective October 29, 2018