

Article XI – Definitions

FREEBOARD – An additional amount of height above the Base Flood Elevation (BFE) used in determining the level at which a structure's lowest floor must be elevated to.

Effective October 29, 2018